

- Suggestions for Floor Foundation Preparation Use gravel stones, to obtain a minimum soil bearing pressure of 49kPa(1024lbs/ft<sup>2</sup>)

- initially poured concrete.
  7. For the first step, pour the concrete with holes prepared for foundation bolts.
  After the concrete has been sufficiently cured, install the foundation bolts, leveling blocks and other fittings and establish the rough level of the machine. For the second step, pour the concrete into the foundation bolt holes to secure the foundation bolts to the floor.